

GRIMAC ROYAL FALCON CORP.

IMPORTERS & WHOLESALE DISTRIBUTORS of BFC Srl ESPRESSO COFFEE MACHINES
100-26 South Jersey Avenue East Setauket, New York 11733 • Tel. 631 • 689-2235 Fax 631 • 689-6773

PROGRAMMING FOR DIADEMA ELECTRONIC SERIES

DOSAGE PROGRAM:

1- Single Cup "Corto" (Short) Dosage.

Press STAR sign Hold until the LED lights go on and release.

Press and release the single cup "short" sign and wait until the coffee volume in the cup reaches the level desired. Press again to stop the flow. The dose is now programmed.

2- Single Cup "Lungo" (Long) Dosage.

Press STAR sign. Hold until the LED lights go on and release.

Press and release the single cup "long" sign and wait until the coffee volume in the cup reaches the level desired. Press again to stop the flow. The dose is now programmed.

3- Double Cup "Corto" (Short) Dosage.

Press STAR sign. Hold until the LED lights go on and release.

Press and release the double cup "short" sign and wait until the coffee volume in the cup reaches the level desired. Press again to stop the flow. The dose is now programmed.

4- Double Cup "Lungo" (Long) Dosage.

Press STAR sign. Hold until the LED lights go on and release.

Press and release the double cup "long" sign and wait until the coffee volume in the cup reaches the level desired. Press again to stop the flow. The dose is now programmed.

NOTE:

Apply the same programming steps to every electronic group assembly on your machine. After you complete your dosage instructions; *do not use the machine for at least 10 seconds* to allow the micro processor to accept the program.

If you have any questions or require any assistance, please contact your local dealer or call GRIMAC ROYAL FALCON CORP. at 631-689-2235